



1. HOW TO SET S/W MODE [ON (DOWN) 0 : ↓ off on / OFF(UP) 1 : ↑ off on]



DIP_SW1 : Navigation On/Off
 DIP_SW2,3 : X
 DIP_SW4 : REAR VIEW CAMERA On/Off
 DIP_SW5,6,7 : X
 DIP_SW8 : On



0,1,1,0,1,1,1,0 : On

※ PLEASE SET AV 1,2,3 FRONT CAMERA ON/OFF ON OSD MENU.

2. HOW TO SWITCH SCREEN :



1. PRESS THIS BUTTON IN SHORT

•PRESS FOR 5 SEC TO TURN On/Off FUNCTION

2. USE TOGGLE SW

3. PRESS THE MENU BUTTON



3. HOW TO SWITCH THE REAR VIEW CAMERA :

NO NEED ADDITIONAL CONNECTION OF THE REAR RAMP SIGNAL ONCE PAS CAN IS CONNECTED

• CONNECT PAS CAN TO SWITCH REAR CAM AUTOMATICALLY

* HOW TO ENTER GPS SETTING MODE





PRESS OK BUTTON 4TIMES THEN YOU WILL SEE THE NUMBER 1 ON THE LEFT TOP OF THE SCREEN FROM 1~4 WHEN IT' S NUMBER 4, PRESS THE OK BUTTON TO ENTER THE SETTING MODE

*Main screen of GPS



*Rear view camera sith P.A.S & F.P.G



[ACCESSORIES]



POWER CABLE



RGB CABLE



IR SENSOR



VIDEO CABLE



PUSH SWITCH



LCD IN/OUT FILM



SUB-BOARD



HEAD UNIT



Separate purchase

R/C

※ E65 MONITER ※

1	3	6
7	9	12

1 : B+
 3 : CAN HIGH
 7 : GND
 9 : CAN LOW

※ POWER CABLE SPEC ※

	ACC, B+
	GND
	CAM REAR 12V OUT
	IR
	CAN HIGH
	CAN LOW
	REVERSE