



2014~ LEXUS (IU30LCH) MANUAL

MAIN UNIT



IU30LCH

Car Brand	Model	Year Range	System
LEXUS	GVIF IU30LCH	2014~	

POWER CABLE FOR 2014~2015 LEXUS

1 POWER CABLE



2 CAN POWER IN/OUT CONNECTOR



3 POWER IN/OUT CONNECTOR OF MONITOR



4 GVIF IN/OUT CABLE



POWER CABLE FOR 2016~2017 LEXUS

1 POWER CABLE



2



3 GVIF IN/OUT CABLE



POWER CABLE FOR 2018 LEXUS 2-1

1 POWER CABLE




2 CAN POWER IN/OUT CONNECTOR



3 POWER IN/OUT CONNECTOR OF MONITOR




4 NEW GVIF IN/OUT CABLE



■ POWER CABLE FOR 2018 LEXUS 2-2

1 BUTTON CAN OF STEERING WHEEL



HOLD




BUTTON OF STEERING WHEEL 2S TO SWITCH MODE

COMPONENTS


※ 9 ~ 15 FOR IU30LCH ※

1 MAIN UNIT	2 POWER CABLE (2014~2015)	3 POWER CABLE (2016~2017)	4 POWER CABLE (2018)	5 RGB CABLE
6 GVIF IN/OUT CABLE	7 R/C	8 HDMI AUDIO CABLE	9 IR CABLE	10 HDMI CABLE ※ OPTION ※
11 AV IN/OUT CABLE ※ OPTION ※	12 AV GENDER CABLE ※ OPTION ※	13 AV GENDER BOARD ※ OPTION ※	14 CAPACITIVE TOUCH CABLE (PCMT6) ※ OPTION ※	15 GVIF2 IN/OUT ※ OPTION ※




CONNECTION (IU30LCH)



■ CONNECTION (IU30LCH)



■ CONNECTION (IU30LCH)



※ CAPACITIVE & RESISTIVE TOUCH SET (OPTION) ※



※ ① USE FOR HDMI MODEL ※

■ DIP S/W [OFF : ↑(UP) / ON : ↓(DOWN)]




DIP_SW1 : NAVI On / Off

DIP_SW4 : REAR CAMERA On/Off


DIP_SW5 : Off

DIP_SW6, 7 : MONITOR SETTING

DIP_SW8 : On




8" 800 X 480



12.3" 800 X 480



12.3" 1280 X 480



12.3" 1280 X 480

■ IU30LCH SPEC

1. INPUT SPEC

- 1 x Analog RGB Input(GPS system output)
- 1 x GVIF Input
- 1 x GVIF output
- 1 x CVBS(rear camera)
- 1 x CVBS(front camera or A/V)
- 1 x HDMI(USE FOR HDMI MODEL)
- 3 x A/V Input(Option)

2. OUTPUT SPEC

- 1 x CVBS
- 1 x Audio L/R


3. POWER SPEC

- Input power : 8VDC ~ 24VDC
- Consumption : 5WATT

4. SIZE

- 154*98*20mm(Width*Length*Height)

5. POWER 24pin



■ HOW TO SWITCH MODE



① , ③ HOLD  BUTTON 2S TO SWITCH MODE


② HOLD  BUTTON 2S TO SWITCH MODE

② PRESS  BUTTON OF STEERING WHEEL TO SWITCH MODE

③ HOLD  BUTTON OF STEERING WHEEL 2S TO SWITCH MODE

④ SWITCH MODE BY EXTERNAL SWITCH 

HOW TO CONNECT VIDEO AUDIO WHEN YOU ONLY USE ONE AV INPUT



HOW TO CONNECT VIDEO AUDIO WHEN YOU USE MORE THAN 2 AV INPUTS

