



FPCM4.0_FP30A MANUAL

MAIN UNIT OF INTERFACE

1

PORSCHE
[FP30A]

Car Brand	Model	Year Range	System
PORSCHE	PCM4.0	2016	
AUDI 3G MMI	3G MMI	2010~2018	

COMPONENTS

1 MAIN UNIT



2 MAIN CABLE



3 IR CABLE



4 LVDS CABLE (A TYPE)




5 REVERSE CABLE




6 REMOTE CONTROL



HOW TO CONNECT



■ DIP S/W OFF : ↑ (UP) / ON : ↓ (DOWN)




DIP_SW4	REAR CAMERA SETTING
OFF	FACTORY REAR
ON	AFTERMARKET REAR
DIP_SW5	CAN SPEED
OFF	100K - LOW SPEED
ON	500K - HIGH SPEED
DIP_SW6	GEAR AUTO or STICK
OFF	STICK (MANUAL)
ON	AUTO
DIP_SW7	RESOLUTION SETTING
OFF	800 X 480
ON	400 X 240
DIP_SW8	ALWAYS ON


■ FP30A SPEC

1. INPUT SPEC
 - 1 x LVDS Input
 - 1 x CVBS(rear camera)
 - 1 x CVBS(front camera or A/V)
2. POWER SPEC
 - Input power : 8VDC ~ 18VDC
 - Consumption : 5WATT
3. SIZE
 - 123*88*20mm(Width*Length*Height)

4. POWER 10pin




HOW TO CONNECT(1-1)



1. PLEASE PULL OUT OEM LVDS CABLE **(A)** , AND LVDS IN CABLE **(B)** OF INTERFACE CONNECT WITH OEM **(A)**.



2. PLEASE USE THE PULLED OUT OEM LVDS CABLE **(A)** CONNECT WITH LVDS IN OF INTERFACE.




3. PLEASE REMOVE THE OEM CONNECTOR **(C)**.



4. PLEASE USE REMOVED OEM CONNECTOR **(C)** CONNECT WITH **(D)** AS PICTURE SHOWN.

HOW TO CONNECT(1-2)



5. PLEASE CONNECT THE CONNECTOR **E** AS PICTURE SHOWN.

★ PDC FUNCTION WILL NOT OPERATE ON VEHICLES WITHOUT P BUTTON




1) CONNECT ORIGINAL CABLE TO AUDI INTERFACE BODY [VIDEO OUT] SOCKET.



2) CONNECT GIVEN LVDS CABLE TO BOTH AUDI ORIGINAL SOCKET AND AUDI INTERFACE BODY [VIDEO IN] SOCKET.



VEHICLE : A4, A5, A6, A7, A8, Q5



VEHICLE : Q3, Q5, Q7(UNDER THE PASSENGER SEAT DRAWER)

FRONT CAMERA SETTING(SETTING FROM REAR VIEW SCREEN)



- VEHICLE : A4, A5, A6, A7, A8
SET ON IN IR MENU WHEN USING FRONT CAMERA SCREEN SWITCH BY PRESSING 'I NAV' BUTTON ON STEERING WHEEL LONG TIME
- VEHICLE : Q3, Q5, Q7
SET ON IN IR MENU WHEN USING FRONT CAMERA SCREEN SWITCH BY PRESSING PDC BUTTON
- FRONT CAMERA SCREEN SHOWS UP AND SOON DISAPPEAR WHEN MOVE BY GEAR[R → P,D,N]ORDER, TIME SETTING CAN BE ADJUSTED IN IR MENU (5,7,9,11SEC.)

HOW TO SWITCH SCREEN(2)

1 HOW TO SWITCH SCREEN MANDATORY BY IR

IT ONLY CAN USE ON ORIGINAL SCREEN
 : R/C **1** OK BUTTON 4TIMES + **2** POWER BUTTON



[R/C]

2 REAR MODE

AVC TYPE
 AVC TIME
 CAN TYPE
REAR MODE
 DEFAULT SETTING

① OEM CAM

REAR MODE
OEM CAM

② AFTER CAM

REAR MODE
AFTER CAM

③ REAR OFF

REAR MODE
REAR OFF