




2016

AP20A

AUDI DIGITAL VIDEO INTERFACE (FPG&PDC)

DOC NO : 22/12/13

1. COMPATIBLE WITH : [(ON) 0 : ↓ off / (OFF) 1 : ↑ off]



DIP_SW1	NAVI On/Off	DIP_SW8	MMI SPEED
OFF	NAVI ON	OFF	LOW
ON	NAVI OFF	ON	HI
DIP_SW2	CAN SPEED	DIP_SW9	RESOLUTION
OFF	100K - LOW SPEED	OFF	800 X 480
ON	500K - HIGH SPEED	ON	400 X 240
DIP_SW3	GEAR AUTO or STICK	DIP_SW10	ON
OFF	STICK		
ON	AUTO		
DIP_SW4	REAR CAMERA		
OFF	OEM REAR		
ON	AFTER REAR		



※AV1/AV2/AV3 in ON/OFF※

- DIP SW1 ON → switch to GPS mode → Enter the OSD setting menu (Press OK button 4times then you will see the number 1 on the left top of the screen from 1~4 when it's number 4, press the POWER button to enter the setting)
- AV → AV1 → SEL → ON



2. HOW TO ENTER NAVIGATION SETTING MODE


[FPG & PDC]



PRESS **OK** BUTTON 4 TIMES THAN YOU WILL SEE THE NUMBER **1** ON THE LEFT TOP OF THE SCREEN FROM 1~4 WHEN IT'S NUMBER 4, PRESS THE BUTTON TO ENTER THE SETTING MODE.

* PLEASE TURN OFF & ON AFTER SETTING

3. HOW TO SWITCH SCREEN



- PRESS SHORT-PRESS 1TIME IN ORDER. [GPS → OEM SCREEN → AV1]
- PRESS **NAV** FOR SHORT(A3,6,7)
- PRESS FOR SHORT TO GO DIRECT TO DMB
- PRESS FOR SHORT TO GO DIRECT TO HOME
- PRESS FOR SHORT TO GO DIRECT TO WORK PLACE
- DMB CHANNEL UP
- DMB CHANNEL DOWN
- BACK** OK




1) CONNECT ORIGINAL CABLE TO AUDI INTERFACE BODY [VIDEO OUT] SOCKET.




2) CONNECT GIVEN LVDS CABLE TO BOTH AUDI ORIGINAL SOCKET AND AUDI INTERFACE BODY [VIDEO IN] SOCKET.

VEHICLE : A4, A5, A6, A7, Q3, Q5, Q7




A8 MMI CABLE IS SAME AS 16' PIN SPEC



MMI(YELLOW/WHITE) AFTER(ORANGE)

VEHICLE : Q3 (under the console box)



[COMPONENTS]

